Remote Control User Guide

ZeroG® Volito



STOP/AUTO PARK – Stops the massage and parks the massage rollers at the top of the backrest.

FULL BACK / UPPER BACK / LOWER BACK – Three unique auto massage programs automatically massage you for 15 minutes each, using a variety of massage modes.

RANGE – Customizes your vertical massage range.

TARGETED MUSCLE BENEFITS – Three massage modes let you customize your massage. Press the Percussion button to toggle the percussion massage between roll, which rolls up and down your back, and zone, which focuses your massage on a six-inch zone.

WIDTH – Focus or diffuse pressure.

STOP – Stops the massage.

CALF/FOOT – Press to toggle through two fixed speeds and an auto massage program.

POWER RECLINE – Press and hold to recline/incline backrest.

POWER FOOTREST DEPLOY – Controls the footrest angle for recline comfort and massage.

POSITION – Use this button, along with any stationary massage mode, to position the massage on your back.

For more detailed operation instructions, please see the Use and Care Manual.

human touch
be your best. feel your best.™